




SPL20 Update Process


The SPL20 updating is made in 3 steps :

- **Step 1:** Turn the SPL in bootloader mode.
For this, open the SPL20 housing and put the jumper in the position indicated below.




Restart SPL20 (by disconnecting then reconnecting the USB cable from SPL20 to PC). SPL20 is now in bootloader mode.

- **Step 2 :** Load the new program of SPL20.
SPL20 is recognized by your computer. Now you must update the new firmware with the supplied software "Rami-AMIX Firmware Updater". For this, launch the software, open the Hex file and click on the "Program" button.



- **Etape 3 :** Put the jumper in its initial position.
Put the jumper in the position indicated below.



Close the SPL's housing. The device is ready to use.